

TURKEY**Antalya****Region:** VI**METAREA:** III**Position:** 36°09'00"N 032°26'00"E

Watch hours on Ch70

Mode Of Transmission	ID SLOT		Frequency	Range
	International	National		
MSI	[D]		490 kHz	400
MSI	[F]		518 kHz	400

Broadcast Times	ID SLOT	Language/Code Form	Contents of Broadcast
0030,0430,0830,1230,1630,2030	[D]	Turkish	Weather forecast for Area Taurus. Navigational warnings: For E. Mediterranean.
0050, 0450, 0850, 1250, 1650, 2050	[F]	English	Weather forecast for Area Taurus.

TURKEY**Istanbul****Region:** VI**METAREA:** III**Position:** 41°04'00"N 028°57'00"E

Mode Of Transmission	ID SLOT		Frequency	Range
	International	National		
MSI	[M]		4 209.5 kHz	400
MSI	[B]		490 kHz	400
MSI	[D]		518 kHz	400

Broadcast Times	ID SLOT	Language/Code Form	Contents of Broadcast
0010,0410,0810,1210,1610,2010	[B]	Turkish	Weather forecast for Areas Marmara and Danube. Navigational warnings: For SW part of Black Sea.
0030,0430,0830,1230,1630,2030	[D]	English	Weather forecast for Areas Marmara and Danube.
0200,0600,1000,1400,1800,2200	[M]	Turkish	

TURKEY**Izmir****Region:** VI**METAREA:** III**Position:** 38°16'00"N 026°16'00"E

Mode Of Transmission	ID SLOT		Frequency	Range
	International	National		
MSI	[C]		490 kHz	400
MSI	[I]		518 kHz	400

Broadcast Times	ID SLOT	Language/Code Form	Contents of Broadcast
0020,0420,0820,1220,1620,2020	[C]	Turkish	Weather Forecast for Areas Aegean and Jason.
0120,0520,0920,1320,1720,2120	[I]	English	Weather Forecast for Areas Aegean and Jason.

TURKEY**Samsun****Region:** VI**METAREA:** III**Position:** 41°23'00"N 036°11'00"E

Mode Of Transmission	ID SLOT		Frequency	Range
	International	National		
MSI	[A]		490 kHz	400
MSI	[E]		518 kHz	400

Broadcast Times	ID SLOT	Language/Code Form	Contents of Broadcast
0000,0400,0800,1200,1600,2000	[A]	Turkish	Weather Forecast for Areas Georgia and Danube. Navigational warnings: For SE part of Black Sea.
0040,0440,0840,1240,1640,2040	[E]	English	Weather Forecast for Areas Georgia and Danube.